

## HAUSNET S.R.L.

Tel Argentina: (+54-11) 5219-2211 Tel Chile: (+56-2) 2897-3999 E-Mail: hausnet@hausnet.com.ar Web: www.hausnet.com.ar

# 26G Series Radar Level Meter




## 26G Radar Level Meter

### 1. Product Overview


This series of radar level meter adopted 26G high frequency radar sensor, the maximum measurement range can reach up to 70 meters. Antenna is optimized further processing, the new fast microprocessors have higher speed and efficiency can be done signal analysis, the instrumentation can be used for reactor, solid silo and very complex measurement environment.

#### • Principle

Radar level transmitter antenna microwave pulse is narrow, the downward transmission antenna. Microwave exposure to the medium surface is reflected back again by the antenna system receives, sends the signal to the electronic circuit automatically converted into level signals (because the microwave propagation speed, electromagnetic wave to reach the target and the reflected back to the receiver this time is almost instantaneous).



- B Zone point
- C Full tank
- D Fade zone



**Datum measurement:** Screw thread bottom or the sealing surface of the flange.

**Note:** Make sure the radar level meter the highest level cannot enter the measuring blind area (Figure D shown below).

#### • The characteristics of 26G radar level meter:

- > Small antenna size, easy to install; Non-contact radar, no wear, no pollution.
- Almost no corrosion, bubble effect; almost not affected by water vapor in the atmosphere, the temperature and pressure changes.
- > Serious dust environment on the high level meter work has little effect.
- > A shorter wavelength, the reflection of solid surface inclination is better.
- Beam angle is small, the energy is concentrated, can enhance the ability of echo and to avoid interference.
- > The measuring range is smaller, for a measurement will yield good results.
- > High signal-to-noise ratio, the level fluctuation state can obtain better

performance.

High frequency, measurement of solid and low dielectric constant of the best choice.

#### 2. Product Introduction



Application: All kinds of corrosive liquid Measuring Range: 10 meters Process Connection: Thread, Flange Medium Temperature: -40°C ~ 120°C Process Pressure: -0.1~0.3 MPa Accuracy: ± 5mm Protection Grade: IP67 Frequency Range: 26GHz Signal Output: 4... 20mA/HART (Two-wire / Four) RS485/ Modbus Explosion-proof Grade: Exia II C T6 Ga

RD91



RD92



Application: Liquid Measuring Range: 30 meters Process Connection: Thread, Flange Medium Temperature: -40°C ~ 150°C Process Pressure: -0.1 ~ 4.0 MPa Accuracy: ± 3mm Protection Grade: IP67 Frequency Range: 26GHz Signal Output: 4... 20mA/HART (Two-wire / Four) RS485/ Modbus Explosion-proof Grade: Exia II C T6 Ga

Application: Solid material, Strong dust Measuring Range: 70 meters Process Connection: Universal Flange Medium Temperature: -40°C ~ 250°C Process Pressure: -0.1 ~ 0.1 MPa Protection Grade: IP67 Accuracy: ± 15mm Frequency Range: 26GHz Signal Output: 4... 20mA/HART (Two-wire / Four) RS485/ Modbus Explosion-proof Grade: Exia II C T6 Ga



Application: Solid material, Strong dust, Measuring Range: 70 meters Process Connection: Universal Flange Medium Temperature: -40°C ~ 250°C Process Pressure: -0.1 ~ 0.1MPa Accuracy: ± 15mm Protection Grade: IP67 Frequency Range: 26GHz Signal Output: 4... 20mA/HART (Two-wire / Four) RS485/ Modbus Explosion-proof Grade: Exia II C T6 Ga

RD94



Application: Solid particles, Powder Measuring Range: 30 meters Process Connection: Thread, Flange Medium Temperature: -40°C ~ 250°C Process Pressure: -0.1 ~ 4.0MPa Accuracy: ± 10mm Protection Grade: IP67 Frequency Range: 26GHz Signal Output: 4... 20mA/HART (Two-wire / Four) RS485/ Modbus Explosion-proof Grade: Exia II C T6 Ga

RD95



**RD96** 

Measuring Range: 20 meters Process Connection: Flange Medium Temperature: -40°C ~ 150°C Process Pressure: -0.1 ~ 4.0MPa Accuracy: ± 3mm Protection Grade: IP67 Frequency Range: 26GHz Signal Output: 4... 20mA/HART (Two-wire / Four) RS485/ Modbus Explosion-proof Grade: Exia II C T6 Ga

Application: Hygienic liquid storage,

Corrosive container

### 3. The Installation Requirements

Installation guide:

Be installed in the diameter of the 1/4 or 1/6. Note: The minimum distance from the tank wall should be 200mm.

- Note: 1) datum 2 The container center or axis of symmetry
- The top conical tank level, can be installed at the top of the tank is intermediate, can guarantee the measurement to the conical bottom.
- A feed antenna to the vertical alignment surface. If the surface is rough, stack angle must be used to adjust the angle of cardan flange of the antenna to the alignment surface.


(Due to the solid surface tilt will cause the echo attenuation, even Loss of signal.)

#### **Typical installation errors:**


Conical tank cannot be installed above the feed port.  $\geq$ Note: outdoor installation should adopt sunshade.


(1) Correct


② Error rainproof measures













The instrument cannot be installed in the arched or domed roof intermediate. In addition to produce indirect echo is also affected by the echoes. Multiple echo can be larger than the real value of signal echo, because through the top can concentrate multiple echo. So cannot be installed in a central location.




> There are obstacles affecting measurement needed reflection plate.



• Height of nozzle:

Correct
 Error

Antenna extends into the tank at least 10mm distance.




## 4. The Electrical Connection

## • The power supply voltage:


(4~20)mA/HART (Two wire system)	The power supply and the output current signal sharing a two core shield cable. The supply voltage range see technical data. For intrinsically safe type must be a safety barrier between the power supply and the instrument.
(4~20)mA/HART(Four wire system)	Separate power supply and the current signal, respectively using a power cable. The supply voltage range see technical data.
RS485 / Modbus	Power supply and Modbus signal line separate drespectively using a shielded cable, the power supply voltage range see technical data.

#### • Connection mode:


> 24V two wire wiring diagram as follows:



> 220V four wire connection is as below:



> 24V RS485/Modbus wiring diagram as follows:




#### • Safety instructions:

- > Please observe the local electrical code requirements!
- Please comply with local requirements for personnel health and safety regulations. All electrical components of instrument operation must be completed by the formal training of professionals.
- Please check the instrument nameplate to provide product specifications meet your requirements. Please make sure that the power supply voltage and instrument nameplate on the requirements.

#### • Protection grade:

:

This instrument meets the protection class IP66/67 requirements, please ensure the waterproof cable sealing head. The following diagram:



#### How to install to meet the requirements of IP67:

Please make sure that the sealing head is not damaged.
Please make sure that the cable is not damaged.
Please make sure that the cable for use with electrical connection specification.
Cable into the electrical interface before its curved downward, ensure that the water will not flow into the shell, see the①
Tighten the cable seal head, see the②
Please electrical interface will not use blind plug tight, see the③

#### 5. Instrument Commissioning


#### • There are three kinds of debugging method:

- 1) Display / Keyboard
- 2) Host debugging
- 3) HART handheld programmer

#### • Display / Keyboard:

Please debug the instrumentation by four buttons on the display screen. There are three debug menu languages optional. After debugging is generally used only for display, through the glass window can read measured value very clearly.

Display / Keyboard




- ① Liquid crystal display(LCD)
- 2 The key


• PC debugging:

Connected to PC by HART


- 1 RS232 interface or USB interface
- 2 Radar level meter
- 3 HART adapter
- (4) 250  $\Omega$  resistor



- HART handheld programmer:
- 1 HART handheld programmer
- ② Radar level meter
- 3 250  $\Omega resistor$





- 6. Structure Size (Unit: mm)
- The outer shell:



• Appearance size:

RD91






RD92




		) ≅
Ē	Ĩ	H+WOT
	1	


Flange	The Bell Diameter D	Beill height. H
DN50	Φ46	140
DN80	φ76	Z27
DN100	Φ96	288









RD95





#### • Flange type:




## 7. Technical Parameters


The outer shell			
The seal between the shell and the shell cover Casing window		Silicone rubber	
		Polycarbonate	
The ground terminal		Stainless steel	
The power supply volta	ige		
Two wire system			
	The standard type	(16 ~ 26) V DC	
	Intrinsically safe	(21.6 ~ 26.4) V DC	
	Power dissipation	max 22.5mA / 1W	
	Allowable ripple		
	- <100Hz	Uss <iv< td=""></iv<>	
	- (100~100K) Hz	Uss <l0mv< td=""></l0mv<>	
The cable parameters			
Cable entrance / plug	One M20xl.5 cable enti	ance	
	One blind plug		
Terminal	Conductor cross sectio	n 1.0mm²	
Output parameters			
The output signal	(4 ~ 20) mA/RS	485	
Communication protocol	HART		
Resolution	1.6u A		
Fault signal	Constant currer	nt output; 20. 5mA	
	22mA		
	3.9mA		
	(0 ~ 50) s, adju		

Blind area	the ends of the antenna	
The maximum distance meas	surement 70 meters	
Microwave frequency	26GHz	
Communication interface	HART com	munication protocol
The measurement interval	about 1 second (depending or	n the parameter settings)
Adjust the time	about 1 second (depending o	n the parameter settings)
Display resolution	1 mm	
Working storage and transpo	ortation temperature	(-40∼100) °C
Process temperature (the temperature of the antenna part) (-40~250)℃		<b>(-40∼250)</b> ℃
Pressure	Max.4MPa	
Seismic	Mechanical vibration I0m/s <sup>2</sup> , (	(10 ~ 150) Hz

## 8. Meter Linearity




Emission angle	Depending on the size of the antenna
-⊄46mm -⊄76mm	18 12°
-⊄96mm	8°
-⊄121mm	6°
Precision	See chart




#### RD93

Emission angle	Depending on the size of the antenna
-⊄46mm	182°
-⊄76mm	12°
-⊄96mm	8°
-⊄121mm	6°
Precision	See chart




Emission angle	Depending on the size of the antenna
-⊄196mm	4°
-¢242mm	4°
Precision	See chart



#### RD95

Emission angle	Depending on the size of the antenna
-⊄76mm	12°
-¢96mm	8°
-⊄121mm	6°
Precision	See chart



Emission angle	Depending on the size of the antenna
-⊄46mm	18°
-⊄76mm	12°
-¢96mm	8°
Precision	See chart

